

Oxygen Conserving Guide



1



Set flow to 4 lpm

2

Connect tube



3



Connect to cylinder

4

Set flow number
using + / -



5



Battery full



Baywater Healthcare | 2 Millennium Gate
Westmere Drive | Crewe | Cheshire | CW1 6XB